ECE R65 CLASS 2 WARNING LIGHTHEAD

Wiring

To -Chassis Ground:BLACK


For High Power Warning: RED - (Fuse Rating @ 2A)

Apply +VDC to RED wire for High Power operation in ECE R65 Class 2*.

For Synchronization:YELLOW -

Connect YELLOW wires of all lightheads together for synchronization. (All lightheads should be set to the same pattern)

*Actual approval will be based on the model purchased.



NOTE: Horizontal mount illustration.

Operation

For Simultaneous or Alternating Synchronization:

- Apply +VDC to RED and YELLOW wires simultaneously to enter grouping mode; lighthead will display short (single or double) flashes.
 - Single flash = Group1
 - · Double flash = Group2
- Remove YELLOW wire from +VDC and momentarily apply to +VDC to change groups.
 - · Lightheads in the same group flash together.
 - . Group1 lighteads alternate with Group2 lightheads.
- Save and exit mode setting by powering off the lighthead.

For Flash Pattern Selection:

Momentarily apply +VDC to YELLOW wire

- · Once for the next pattern.
- Quick three times to FP#1. (see flash pattern chart)

NOTE: This unit may not be factory-set at flash pattern #1.



					$\overline{}$
Flash Pattern					
1	Double	[R65]*	16	Single H/L	
2	Single	[2HZ]	17	Single-Triple-Quint	
3	Triple	[2HZ]	18	Half-Steady-Half-Double	(split)
4	Quad	[2HZ]	19	Single	(split)
5	Random		20	Double	(split)
6	Steady		21	Triple	(split)
7	Single	[SAE/CA13]	22	Quad	(split)
8	Double	[SAE]	23	Quint	(split)
9	Triple	[SAE]	24	Mega	(split)
10	Quad	[SAE]	25	Giga	(split)
11	Quint	[SAE]	26	Ultra	(split)
12	Mega		27	Single-Quad	(split)
13	Giga		28	Single H/L	(split)
14	Ultra	[SAE]	29	Single-Triple-Quint	(split)
15	Single-Quad				

^{*} Actual approval will be based on the model purchased.